Catalog Number	Frame Color	Seat Color
ECO Chair™		
333-BLK	Black	
333-SND	Sand	
333-GRY	Light Gray	
333-BRN	Dark Brown	
Plastic High Chai	r, Assembled	
850DGY	Gray	Gray
850BRN	Brown	Black
Plastic High Chai	r, Unassembled	
850DGY-KD	Gray	Gray
850BRN-KD	Brown	Black
Plastic High Chai	r with Casters, Asse	mbled
850C DGY	Gray	Gray
850C BRN	Brown	Black
Plastic High Chai	r with Casters, Unss	embled
850C DGY-KD	Gray	Gray
850C BRN-KD	Brown	Black
High Chair Tray		
851DGY	Gray Plastic Tray	
851BLK	Black Plastic Tra	у
KidSitter™ Multi-l	Use Plastic High Cha	ir
866	Dark Brown	See Below
877	Light Gray	See Below
888	Beige	See Below
KidSitter™ Multi-l	Use Plastic High Cha	ir with Casters
866C	Dark Brown	See Below
877C	Light Gray	See Below
888C	Beige	See Below
KidSitter™ Replac	ement Seat Belts	
8814S	Beige	
8814SBK	Black	
KidSitter™ Fran	ne Finish Options	
Light Gray Beige	Dark Brown	

Plastic High Chairs

ECO Chair™

The ECO Chair from CSL boasts a roomier, more comfortable alternative to conventional commercial high chairs. In addition, ECO Chair is manufactured from recycled material, making it the industry's first high chair made from 100% recycled plastic.

Catalog Number: 333-BLK 29.50"H x 17.25"W x 23.50"D

 Made from 100% Recycled Plastic

• Larger Seating Area

- Lightweight • Easy to Clean
- Easy Assembly
- Available in Black, Sand, Light Gray & Dark Brown



Unassembled high chairs

ship flat and assemble

in minutes! 🔻



Plastic High Chair Catalog Number (Assembled): 850 Catalog Number (Unassembled): 850-KD 29.375"H x 22.375"W x 22.375"D



Dark Gray High Chair Tray Catalog Number: 851DGY



Plastic High Chair with Casters Catalog Number (Assembled): 850C Catalog Number (Unassembled): 850C-KD 32.375"H x 22.375"W x 22.375"D



Black High Chair Tray Catalog Number: 851BLK







KidSitter™Multi-Use Plastic High Chair Catalog Number: 866, 877, 888 27"H x 22.5"W x 22"D Also Available with Casters



KidSitter™Replacement Seat Belts Catalog Number: 8814S, 8814SBK 36" Length

Dark Brown

Blue (BLU)

Green (GRN)

Dark Gray Black (DGY) (BLK)



Step 3: Stow Seat



Step 2: Swing Seat

Step 4: Place Car Seat

Wood High Chairs



Deluxe Wood High Chair Catalog Number: 803BL (shown) 27.5"H x 19"W x 20"D

Wood Booster Seat



Available with or without strap. **Wood Booster Seat** Catalog Number: 840SB 10.5"H x 11.75"W x 11.75"D

Replacement Straps



Replacement Seat Belt 800/822 Series Wood High Chairs Catalog Number: 75014S

Replacement Crotch Strap Wood High Chairs (Not Shown) Catalog Number: P3239-15P

Infant Seat Carrier



Folding Infant Seat Carrier Catalog Number: 0836 26"H x 22"W x 26"D



Economy Plus Wood High Chair Catalog Number: 822LT (shown) 27.5"H x 19"W x 20"D

Plastic Booster Seats



Plastic Booster Seat Catalog Number: 857 8" H x 15.5" W x 12" D

without strap.

Changing Stations



Vertical Baby Changing Station Catalog Number: 4100 15.25"H x 12"W x 13.5"D




Horizontal Baby Changing Station Catalog Number: 4000 16"H x 34.25"W x 18"D

Catalog Number	Finish Color	Si Co
Deluxe Wood High Cha	nir	
800LT	Light	ВІ
801DK	Dark	В
803BL	Black	В
804MH	Mahogany	В
Economy Plus Wood H	igh Chair	
822LT	Light	В
824DK	Dark	В
Wood Booster Seat		
0840	Light	
0840SB	Light	В
Plastic Booster Seat		
855BLU	Blue	
855BRN	Brown	
855DGY	Dark Gray	
855GRN	Green	
855RED	Red	
Plastic Booster Seat w	ith Straps	
857BLU	Blue	В
857BRN	Brown	В
857DGY	Dark Gray	В
857GRN	Green	В
857RED	Red	В
Replacement Seat Belt	- 800 Series High Chai	rs & Boo
75014S		В
Replacement Crotch St	ap - 800 Series Wood	High Cha
P3239-15P		В
Folding Infant Seat Ca	rrier	
0836	Beige	
Vertical Baby Changin	g Station	
4100	Natural	
Horizontal Baby Chang	ing Station	
	Natural	
4000	IVaturai	
4000 Baby Changing Station		count

















Dark Gray



