



- 1 **#5000-0020** – 7" Swing Spout (page 95)
#5000-0001 – 10" Swing Spout
#5000-0002 – 14" Swing Spout
Includes Spout O-Rings **#5000-5001** (page 106)
- 2 **#5000-0003** – 10" DJ Sub-Assembly (page 95)
Includes Spout O-Rings **#5000-5001**
- 3 **#5000** – Single Wall Control Valve, Inlet 3/4"F X 2"LG (page 94)
Stem RH Swivel Repair Kit #5000-0010 (page 101)
- 4 **#5300** – 8" Deck Control Valve, Inlets 3/4"M X 2"LG (page 94)
Hot Stem RH Swivel Repair Kit #5000-0010 (page 101)
Cold Stem LH Swivel Repair Kit #5000-0011 (page 101)
- 5 **#5700** – Single Wall Control Valve, Inlet 3/4"F (page 94)
Stem RH Swivel Repair Kit #5000-0010 (page 101)
- 6 **#10219** – Nipple w/ Locknut and Washer (page 92)
- 7 **#5000-2103** – 3/4"F Elbow Close (page 92)
- 8 **#5400** – 8" Backsplash Control Valve, Inlets 3/4"F Elbows (page 94)
Hot Stem LH Swivel Repair Kit #5000-0011 (page 101)
Cold Stem RH Swivel Repair Kit #5000-0010 (page 101)
- 9 **#5200** – 8" Adj. Wall Control Valve, Inlets 3/4"F Eccentrics (page 94, 106)
Hot Stem LH Swivel Repair Kit #5000-0011 (page 101)
Cold Stem RH Swivel Repair Kit #5000-0010 (page 101)
- 10 **#5010** – 8" C/C Backsplash Control Valve with 3" Turndown Spout, Inlets 3/4"F Elbows
Hot Stem LH Swivel Repair Kit #5000-0011 (page 101)
Cold Stem RH Swivel Repair Kit #5000-0010 (page 101)
- 11 **#5011** – Adj. Wall Control Valve with 3" Turndown Spout, Inlets 3/4"F Eccentrics
Hot Stem LH Swivel Repair Kit #5000-0011 (page 101)
Cold Stem RH Swivel Repair Kit #5000-0010 (page 101)

Standard Components

Optional Components

* Optional handles available (page 92, 102)
Vandal Resistant Kit available (page 93)