
Portable Hot Water Boilers CS113 CS115



SPECIAL FEATURES:

; PORTABLE, EASILY MOVED TO ANY CONVENIENT LOCATION.

; PRECISION THERMOSTAT FOR ACCURATE TEMPERATURE CONTROL.

; SIGHT GLASS INDICATES WATER LEVEL.

Cecilware sells value... Worldwide Cecilware Corporation

43-05 20th Avenue, Long Island City, NY 11105
Tel: 718-932-1414 Fax: 718-932-7860

800-935-2211 E-Mail: customer.service@cecilware.com


CECLWARE

Website: www.cecilware.com

Portable Hot Water Boilers CS113 CS115

Electrical Specifications:

1.6KW 120Volts or 2.4KW 220V (export)



Size Specifications:

MODEL NO	CAPACITY	DIAMETER	HEIGHT	WEIGHT
CS113	3 Gals	11 in.	21 ½ in.	15 lbs.
CS115	5 Gals	11 in.	27 ½ in.	18 lbs.

Line Cord is included

CAUTION: Do not run the unit dry (without water)

Turn thermostat knob all the way counterclockwise to OFF position.

Fill with fresh water, plug into electric outlet, then turn thermostat knob clockwise to the desired temperature (between 5 and 8).


Hot Water Boilers:

Fill with fresh water, plug into electric outlet, then turn thermostat knob clockwise to the desired temperature (between 5 and 8).

Cleaning Instructions:

- 1. Wipe exterior with a soft, damp cloth.
- 2. Clean urn inside with mild soap and water. Rinse thoroughly.

PARTS LIST CS113 CS115



PARTS LIST

ITEM DESCRIPTION	PART NO		
1 URN COVER KNOB	M027A		
2 COVER, URN	Q004A		
3 SCREW, PAN HD PHIL S.S. 10-24x1/2	P264A	14 HI-LIMIT	L573A
4 GAUGE GLASS SHIELD 8" (CS113)	D023A	15 STRAIN RELIEF	B012A
5 GAUGE GLASS SHIELD 10 3/4" (CS115)	D020A	16 LINE CORD	C032A
6 GAUGE SHANK		17 BOTTOM, WATER COMPARTME	NT Q187A
7 FAUCET	D064A	18 URN BODY (CS113)	R045A
8 SCREW, THERMOSTAT		19 URN BODY (CS115)	R046A
	A800M	20 HANDLE	M007A
10 THERMOSTAT	L005A	21 PLUG IN COLLAR	Q012A
11 SCREW, 8-32 x 3/8 SELF TAP	P140A	22 HEATER ELEMENT 120 V	G193A
12 HOLE PLUG (1.250 DIA)	P300A	23 HEATER ELEMENT 220 V	G359A
13 BOTTOM COVER	Q186A	24 PILOT LIGHT	C002A