

Blow Off™ 134a Non-Flammable Duster

DESCRIPTION

Blow Off™ Air Duster, Non-Flammable 10 oz. removes dust, dirt and microscopic debris from hard to reach areas of home and office equipment. It's non-flammable.

RECOMMENDED FOR

Computers • Keyboards • Sewing Machines • Photo Equipment • Cash Registers • Printers • Fax Machines • Copiers • Telephones • Lab Equipment • TVs • VCRs • Typewriters • Vacuums • Shredders • Scanners • Stereos • Watches • Clocks • Mailing Machines • Fans • Audio Equipment • Electric Razors • Sports Equipment • Musical Instruments • Guns • Desk Tops

PRODUCTS

SKU

NF-111-137 BLOW OFF 134A AIR DUSTER 10 OZ.

DIRECTIONS

Point Nozzle Away from yourself or others. Insert extension tube firmly. Place finger on trigger when removing the tab from the top of the trigger assembly. Tear tab from trigger assembly. Hold can in an upright position. Spray in short even bursts. Do not shake before or during use.

IMPORTANT USAGE INFORMATION

NEVER shake or tilt can before or during use. Use only in upright position.

AVOID skin contact with product in liquid form, may cause frostbite

ENERGIZED EQUIPMENT USE ONLY

FEATURES

- ▶ All purpose sterilized cleaner. Non-Flammable and ozone safe.
- ▶ Removes dust, dirt and microscopic debris from hard to reach places.

SPECIFICATIONS

Net Wt.:	10 oz.
Individual Size:	2.5" x 2.5" x 8.5"
Individual Weight:	0.87 lbs.
Case Qty.:	12 Cans
Case Dims:	10.75" x 8.25" x 9.25"
Case Weight:	10.44 lbs.
Shelf Life:	4 - 5 years
Safety Info:	See SDS Sheet

