

# PRODUCT N\*E\*W\*S

TOP SHELF UNDERBAR  
Faucet Controller  
April 23, 2010

## NOW AVAILABLE ELECTRONIC "TOUCH FREE" FAUCET ADAPTER

### Electronic "Touch-Free" Faucet Adapter:

This unit converts most faucets into an automatic "Touch-Free" faucet. Simply remove the faucet aerator and install the universal adapter to end of the spout with a simple screw-on installation.

An infrared sensor stops water flow automatically and a 3-minute automatic time-out feature minimizes the chance of accidental overflow. The manual on/off over-ride button provides constant flow to fill sink or containers.

**Part Number: UAC-EFA**



8300 W. Good Hope Road ♦ Milwaukee, WI 53223 ♦ Phone 414-353-7060 ♦ Fax 414-353-7069