

Service line to equipment does not have to be removed to introduce sanitizer.

Surge tank sanitizing is easier, safer and quicker.

INSTALLATION TIPS

cartridges.

Kit before sanitizing.

one gallon of water.

Kay5 sanitizer.

Obtain the appropriate system replacement

Check for all parts in High Flow Sanitizing

Obtain a clean bucket that can hold at least

Use an acceptable sanitizer product; either

5-1/4% unscented chlorine bleach or

Use eye, hand, and clothing protection.

OPERATION TIPS

Turn off power to equipment prior to start.

Turn off water to filter system and depressurize system before removing bowls and cartridges.

Remove Scalestick[®] and do not replace until sanitization is complete.

Use potable water only and do not cleaan the prefilter or SR - X bowls with special cleaners, soaps or detergents.

Flush all cartridges and check for residual chlorine with tests strips provided

Prior to restarting system make sure: a) Flush valve is closed b) Inlet valve is open c) Surge tank valve is open (if present).

Restore power to affected equipment.

A P P L I C A T I O N / S I Z I N G

Sanitizes the following systems:

- High Flow CSR Systems:
- Twin MC
- Triple MC and Triple MC w/Alarm
- Quad MC and Quad MC w/Alarm Plus XC and Plus XC w/Alarm

Insurice Systems: - Single PF-i2000(2)

- Twin PF-i2000(2)
- Triple PF-i2000(2)

Coldrink Systems: - Coldrink I-MC(2)

- Coldrink 2-MC(2) - Coldrink 3-MC(2)

Single Tank: - 9 and 12 gallon

Clear Tubing ~ 1/2" O.D. x 3/8" I.D. 3/4" MNPT Union and Barb Adapter

S P E C I F I C A T I O N S

Overall Dimensions: 17"W x 15"H x 4.5"D

Pressure Requirements: 10 - 125 psi (0.7 - 8.6 bar) non-shock

Temperature: 35° - 100° F (2° - 38° C)

The contaminants or other substances removed or reduced by this drinking water system are not necessarily in your water. Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system. Systems certified for cyst reduction may be used with disinfected water that may contain filterable cysts. Everpure

WARRANTY

Everpure water treatment systems (excluding replaceable elements) are covered by a limited warranty against defects in material and workmanship for a period of five years after date of purchase. Everpure replaceable elements (filter cartridges and water treatment cartridges) are covered by a limited warranty against defects in material and workmanship for a period of one year after date of purchase. See printed warranty for details. Everpure will provide a copy of the warranty upon request.



Worldwide Headquarters: EVERPURE, LLC 1040 Muirfield Drive Hanover Park, Illinois 60133 Toll Free (800) 323-7873 Tel (630) 307-3030 http://www.everpure.com In Europe: Pentair Water Belgium B.V./B.A. Industriepark Wolfstee Toekomstlaan 30 B-2200 Herentals BELGIUM TEL: +32.(0).14.283,500 FAX: +32.(0).14.283,505 In Japan: Hashimoto MN Bldg, 7F 3-25-1 Hashimoto Sagamihara-Shi Kanagawa 229-1103 JAPAN TEL: 81.(0)42.775.301 FAX: 81.(0)42.775.3015

Everpure 1040 Muirfield Drive Hanover Park, IL 60133

High Flow System Sanitizing Kit