ESO⁷ Cartridge

Unique three stage blending cartridge provides softened/buffered/filtered water



APPLICATIONS

Specialty coffee Espresso Ice tea

FEATURES AND BENEFITS

Unique three stage blending cartridge provides softened/buffered/filtered water.

Utilizes ion exchange resin, with buffering capabilities and high capacity coconut carbon filtration.

Small amount of carbon filtered water bypasses softening resin to allow proper initial hardness.

Buffering prevents water from becoming too acidic.

Reduces hardness in water that can cause minerals to build-up in coffee and espresso equipment.

Reduces minerals such as calcium and magnesium.

Reduces chlorine, off tastes and odors.

Sanitary cartridge replacement is simple, quick and clean. Internal filter parts are never exposed to handling or contamination.

OPERATIONAL TIPS

Change ESO⁷ cartridge when its pre-calculated water volume has been reached or at least once a year.

Performance will be reduced if recommended service flow rate is exceeded.

Always flush the filter cartridge at time of installation and cartridge change.

Everpure water treatment systems (excluding replaceable elements) are covered by a limited warranty against defects in material and workmanship for a period of five years after date of purchase. Everpure replaceable elements (filter cartridges and water treatment cartridges) are covered by a limited warranty against defects in material and workmanship for a period of one year after date of purchase. See printed warranty for details. Everpure will provide a copy of the warranty upon request.



ESO⁷ Replacement Cartridge: EV9607-25

SPECIFICATIONS

Overall Dimensions: Service Flow Rate: Rated Capacity:

Filtration Capacity:

Pressure Requirements: Temperature: Electrical Connection: 20.75" H x 3.25" D (52.7 x 8.2cm) Maximum 0.5 gpm (1.9 Lpm) 5,300 grains (single configuration)* 10,600 grains (twin configuration)* 15,900 grains (triple configuration)* 600 gallons (2,300 L) @ 150 ppm

10 – 125 psi (0.7 – 8.6 bar), non-shock 35 – 100°F (2 – 38°C) None *Cartridge Grain Capacity divided by Grains Per Gallon in Influent Water = Total Product Water



ESO⁷ Cartridge EV9607-25

INSTALLATION TIPS


Choose a mounting location suitable to support the full weight of the system when operating.

Use 3/8" water line.

Install vertically with cartridge hanging down.

Allow 2-1/2" clearance below the cartridge for easy cartridge replacement.

 $\mathsf{Flush}\,\mathsf{ESO}^7$ cartridge by running water through filter for five minutes at full flow.



The contaminants or other substances removed or reduced by this drinking water system are not necessarily in your water. Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system. Systems certified for cyst reduction may be used with disinfected water that may contain filterable cysts.

EVERPURE reserves the right to update specifications, change prices, or make substitutions without notice.

Everpure-Shurflo China

21F Cloud 9 Plaza, No 1118,

West Yan'an Road, Changning District

Shanghai, 200052

CHINA

TEL: 86.21.3211.4588

FAX: 86.21.3211.4580

Everpure-Shurflo India A-25 Mohan Co-operative Industrial Estate Mathura Road New Dehii, 110 044 INDIA TEL: 011.661.188.00 FAX: 011.661.188.22

Everpure-Shurflo Japan Inc. Hashimoto MN Bldg. 7F 3-25-1 Hashimoto, Midori-ku Sagamihara-Shi Kanagawa 252-0143 JAPAN TEL: 81.(0)42.775.3011 FAX: 81.(0)42.775.3015



WATER YOU CAN TRUST®

Visit our website at www.everpure.com

Pentair Filtration Solutions, LLC World Headquarters-Everpure/Shurflo North and South America Sales 1040 Muirfield Dr. Hanover Park, Illinois 60133 USA TEL: 800.323.7873 (US only) TEL: 630.307.3000 FAX: 630.307.3030 Everpure-Shurflo Southeast Asia 18 Boon Lay Way #04-110/111 TradeHub 21, 609966 SINGAPORE TEL: 65.6795.2213 FAX: 65.6795.2219

Everpure-Shurflo Australia 2 Redwood Drive Notting Hill Victoria, 3168 AUSTRALIA TEL: 011.61.39.574.4000 FAX: 011.61.39.562.7237 Everpure-Shurflo Europe byba Industriepark Wolfstee Toekomstlaan 30 B-2200 Herentals BELGIUM TEL: +32.(0).14.283.500 FAX: +32.(0).14.283.505

EV9607-25 AU10