



EV9628-28

# Quad-MC<sup>2</sup> Cartridge Kit

Replacement cartridge kit for Everpure High Flow CSR Quad-MC<sup>2</sup> Systems



Quad-MC<sup>2</sup> Replacement Cartridge Kit:  
EV9628-28

## BENEFITS

Convenient replacement cartridge kit contains all necessary cartridges to service filters in specific High Flow CSR Quad combination systems.

Kit includes (1) EC210 prefilter, (4) MC<sup>2</sup> filter cartridges, and (1) SS-IMF with spacer

Reduces chlorine taste and odor and other offensive contaminants that can adversely affect the taste of beverages

New and improved Micro-Pure II media with AgION™ antimicrobial protection inhibits any potential bacterial growth

Precoat submicron technology reduces dirt and particles as small as 1/2 micron in size and reduces possible health contaminants such as asbestos fibers and Cryptosporidium and Giardia cysts

20" prefilter cartridge captures larger dirt particles and extends the life of the MC<sup>2</sup> cartridges

SS-IMF cartridge inhibits limescale buildup in ice machines and coffee brewers (as tested by Everpure).

MC<sup>2</sup> cartridges are NSF Certified under NSF/ANSI Standards 42 and 53. SS-IMF cartridge is NSF component listed

## INSTALLATION TIPS

Install vertically with cartridges hanging down

Allow 2-1/2" clearance below the cartridge for easy cartridge replacement

Flush cartridges by running water through system for five minutes at full flow

Install SS-IMF cartridge in SR-X bowl vertically with black o-band seal up

## OPERATION TIPS

Change cartridges on a regular 6 month preventative maintenance program

Change cartridges when capacity is reached or when pressure falls below 10 psi

Change SS-10 cartridge before Hydroblend™ compound is completely used up

Replace EC210 cartridge when dirt has penetrated through to the inner core of the cartridge

Always flush the filter cartridges at time of installation and cartridge change

## APPLICATION/SIZING

Replacement cartridge kit for Everpure High Flow CSR Combination Systems

For foodservice applications

# Quad-MC<sup>2</sup> Cartridge Kit

## SPECIFICATIONS

### Overall Dimensions:

MC = 20"H x 4"W x 4"D ; EC210 = 20"H x 3.38" Diameter ; SS-IMF = 6-7/8"H x 1-5/16" Diameter

The SS-IMF Spacer (EV3114-69) may be used to extend the height of the SS-IMF cartridge by approximately 1-3/4" for a better fit into longer bowls.

### Service Flow Rate:

Maximum 6.7 gpm (25.4 Lpm)

### Pressure Requirements:

10 psi - 125 psi (0.7 – 8.6 bar), non-shock

### Temperature:

35°F - 100°F (2-38°C)

The contaminants or other substances removed or reduced by this drinking water system are not necessarily in your water. Do not use with water that is microbiologically unsafe or of unknown quality without adequate disinfection before or after the system. Systems certified for cyst reduction may be used with disinfected water that may contain filterable cysts.

## WARRANTY

Everpure water treatment systems (excluding replaceable elements) are covered by a limited warranty against defects in material and workmanship for a period of five years after date of purchase. Everpure replaceable elements (filter cartridges and water treatment cartridges) are covered by a limited warranty against defects in material and workmanship for a period of one year after date of purchase. See printed warranty for details. Everpure will provide a copy of the warranty upon request.



System Tested and Certified by NSF International against NSF/ANSI Standard 42 and 53 for the reduction of:

Standard No. 42: Aesthetic Effects  
Chemical Unit  
Taste and Odor Reduction  
Chlorine Reduction  
Mechanical Filtration Unit  
Nominal Particulate Reduction,  
Class 1: 99.2% reduction of particles  
one-half micron and larger in size

Standard No. 53: Health Effects  
Mechanical Filtration Unit  
Turbidity Reduction  
Cyst Reduction  
Asbestos Reduction



*Worldwide Headquarter :*  
EVERPURE, LLC  
1040 Muirfield Drive  
Hanover Park, Illinois 60133  
Toll Free (800) 323-7873  
Tel (630) 307-3000  
Fax (630) 307-3030  
<http://www.everpure.com>

*In Europe:*  
Everpure Europe bvba  
Industriepark Wolfstee  
Toekomstlaan 30  
B-2200 Herentals  
BELGIUM  
TEL: +32.(0).14.283.500  
FAX: +32.(0).14.283.505

*In Japan:*  
Everpure Japan Inc.  
Hashimoto MN Bldg. 7F  
3-25-1 Hashimoto Sagamihara - Shi  
Kanagawa 229-1-1103  
JAPAN  
TEL: 81.(0)42.775.3011  
FAX: 81.(0)42.775.3015