
888-310-4393 • 120 Frontage Road, Altamont, IL 62411 • www.bk-resources.com

visit our website:

Jet Faucet Model: BKF-JET-G, Lead Free








Product Specifications:

- Single Hole Polished Chrome Plated Touch-Free Faucet for Cold or Premixed Water
- Lead Free Product
- 0.5 GPM (1.9 L/min) Vandal Resistant Aerator
- Preset Sensor Range: 8 21/22" Adjustable
- Minimum Sensor Range: 3 5/32
- Maximum Sensor Range: 11 13/16"
- · Available with a 9V Battery or a 9V Transformer
- Operating Pressure: 7-100 PSI
- Max Operating Temperature: 158° F
- Security Time: The Faucet will Shut Down Automatically After 90 Seconds
- Adjustable Sensor Settings by Remote Control

Maintenance:

DO NOT use steel wool or cleansing agents containing alchohol, acid, abrasives or the like. Use of any prohibited cleaning or maintenance products or substances could damage surface of the faucet. For surface cleaning of faucet use ONLY soap and water, then wipe dry with clean cloth or towel. When cleaning bathroom tile, the faucets should be protected from any splattering of harsh cleansers.





Certifications:















RESOURCES

888-310-4393 • 120 Frontage Road, Altamont, IL 62411 • www.bk-resources.com

Jet Faucet

Model: BKF-JET-G, Lead Free





1 1 BKF-JET-G Faucet Body 2 1 JET-IRS Infra Red Sensor 3 1 JET-SO Spout O-Ring 4 1 JET-SS Set Screw 5 1 JET-BO Base O-Ring 6 1 JET-INSERT Insert 7 1 JET-BO2 Base O-Ring 8 1 JET-BG Base Gasket 9 1 JET-DISK Base Disk 10 1 JET-MN Mounting Nut 11 1 JET-WL Water Line 12 1 JET-SEN-O Sensor O-Ring	Diagram #	Quantity	Part Number	Description
3 1 JET-SO Spout O-Ring 4 1 JET-SS Set Screw 5 1 JET-BO Base O-Ring 6 1 JET-INSERT Insert 7 1 JET-BO2 Base O-Ring 8 1 JET-BG Base Gasket 9 1 JET-DISK Base Disk 10 1 JET-MN Mounting Nut 11 1 JET-WL Water Line	1	1	BKF-JET-G	Faucet Body
4 1 JET-SS Set Screw 5 1 JET-BO Base O-Ring 6 1 JET-INSERT Insert 7 1 JET-BO2 Base O-Ring 8 1 JET-BG Base Gasket 9 1 JET-DISK Base Disk 10 1 JET-MN Mounting Nut 11 1 JET-WL Water Line	2	1	JET-IRS	Infra Red Sensor
5 1 JET-BO Base O-Ring 6 1 JET-INSERT Insert 7 1 JET-BO2 Base O-Ring 8 1 JET-BG Base Gasket 9 1 JET-DISK Base Disk 10 1 JET-MN Mounting Nut 11 1 JET-WL Water Line	3	1	JET-SO	Spout O-Ring
6 1 JET-INSERT Insert 7 1 JET-BO2 Base O-Ring 8 1 JET-BG Base Gasket 9 1 JET-DISK Base Disk 10 1 JET-MN Mounting Nut 11 1 JET-WL Water Line	4	1	JET-SS	Set Screw
7 1 JET-BO2 Base O-Ring 8 1 JET-BG Base Gasket 9 1 JET-DISK Base Disk 10 1 JET-MN Mounting Nut 11 1 JET-WL Water Line	5	1	JET-BO	Base O-Ring
8 1 JET-BG Base Gasket 9 1 JET-DISK Base Disk 10 1 JET-MN Mounting Nut 11 1 JET-WL Water Line	6	1	JET-INSERT	Insert
9 1 JET-DISK Base Disk 10 1 JET-MN Mounting Nut 11 1 JET-WL Water Line	7	1	JET-BO2	Base O-Ring
10 1 JET-MN Mounting Nut 11 1 JET-WL Water Line	8	1	JET-BG	Base Gasket
11 1 JET-WL Water Line	9	1	JET-DISK	Base Disk
	10	1	JET-MN	Mounting Nut
12 1 JET-SEN-O Sensor O-Ring	11	1	JET-WL	Water Line
	12	1	JET-SEN-O	Sensor O-Ring
13 1 JET-SPT Spout	13	1	JET-SPT	Spout




Diagram #	Quantity	Part Number	Description
14	1	JET-AER	Aerator
15	1	JET-SB	Solenoid Body
16	1	JET-FILTER	Filter
17	1	JET-N	Nipple
18	1	JET-D	Diaphram
19	1	JET-SV	Solenoid Valve
20	1	JET-9V	Battery Box